



PETER CHOU model USP-9 Power Supply Repair Guide

Screw terminal gray painted metal case style power supply with power on indicating LED.




PETER CHOU model USP-9 Power Supply Repair Guide

Symptoms:

No operation (appears dead when AC power applied) or intermittent operation. Fuse is NOT blown.

Cause:

Resistors R6 and/or R11 are open. Both are 330 k @ ½ watt. If only one of two are found bad, it's a good idea to replace them both with new ones.



PETER CHOU model USP-9 Power Supply Repair Guide

